


ASSEMBLY INSTRUCTIONS



Finestra 3-Light Arc Lamp

1. Carefully remove all 3-light parts from the box.
2. Secure section(A) to base(B) and insert washer (C) and secure with nut (D) using key (E) - provided.
3. Stand the now assembled arc base on a level surface.
4. Connect Connector (G) to Connector (F), (G) is located at the bottom of arc arm (I), (F) is located at end of section (A).
5. Insert the connected cables (F and G) into section (A) and insert arc arms (I) and secure with screw (H).
6. Attach shade (K) to socket (J) followed by lock ring (L), then insert bulb (M) - PROVIDED, repeat this step for the remaining arc heads.



IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

INSTRUCCIONES DE ENSAMBLE

Finestra Arco de 3-luces

1. Cuidadosamente remueva de la caja todas las partes de la lampara.
2. Asegure seccion (A) a la base (B) inserte la rondona (C) y atornille con tuerca (D) usando la llave (E) - proveida.
3. Pare la Base ensamblada en una superficie plana.
4. Conecte el conector (G) con el conector (F), (G) esta localizado abajo de los brazos de arco (I), (F) esta localizado en la seccion (A).
5. Inserte los cables conectados (F e G) en la seccion (A), inserte los brazos del arco (I) en la seccion (A) y asegure con la tuerca (H).
6. Conecte la pantalla (K) a la cabeza del arco (J) seguido por rondona (L) e inserte foco (M) - PROBEIDO, repita este paso para las otras pantallas.

IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Esta lampara tiene un enchufe polarizado (una navaja es mas ancha que la otra) como forma de seguridad para reducir el riesgo de un shock electrico. Este enchufe polarizado entrara en una conecion solo de un lado. Si el enchufe no entra en la conecion trate el reverso. Si aun asi no entra, contacte un electricista calificado. Nunca use una extension a menos que el enchufe pueda ser conectado completamente. No altere el enchufe.

