

# ASSEMBLY INSTRUCTIONS



## Brim Floor Lamp

1. Carefully remove all lamp parts from the box. Please see list of items included in box.
2. Stand lamp base (A1) on a flat surface and screw on base pole (A2) securing firmly.
3. Secure base pole (A3) onto base pole (A2) by screwing in firmly.
4. Insert shade holder (A4) to lamp socket (B) followed by shade (C) to socket (B).
5. Secure shade (C) using lock ring (D).
6. Insert bulb (G) - (NOT INCLUDED) onto lamp socket (B).
7. Attach diffuser (E) to threading on shade (C) using finial (F).
8. Adjust lamp to desired height using lever on lamp base (A3).

## IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.


## INSTRUCCIONES DE ENSAMBLE

### Brim Lampara de Piso

1. Cuidadosamente remueva de la caja todas las partes de la lampara. Por favor consulte lista de articulos incluidas.
2. Pare la base de la lampara (A1) en una superficie plana y atornille varilla (A2) asegurandola.
3. Asegure varilla (A3) a varilla (A2) atornillandola firme.
4. Inserte soporte (A4) a enchufe (B) seguido por pantalla (C) a enchufe (B).
5. Asegure pantalla (C) usando rondana (D).
6. Inserte bombilla (G) - (NO INCLUIDO) a enchufe (B).
7. Adjunte difusor (E) en cima de la rosca de pantalla (C) y asegure con pínaculo (F).
8. Para ajustar la lampara a altura deseada use nivelador localizado en varilla (A3).

## IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Esta lampara tiene un enchufe polarizado (una navaja es mas ancha que la otra) como forma de seguridad para reducir el riesgo de un shock electrico. Este enchufe polarizado entrara en una conexión solo de un lado. Si el enchufe no entra en la conexión trate al reverso. Si aun asi no entra, contacte un electricista calificado. Nunca use una extension a menos que el enchufe pueda ser conectado completamente. No altere el enchufe.



ITEMS INCLUDED / ARTICULOS INCLUIDAS				
A1,A2,A3,A4, B	C	D	E	F
LAMP BASE BASE DE LAMPARA	SHADE PANTALLA	LOCK RING RONDANA	DIFFUSER DIFUSOR	FINIAL PÍNACULO