


# ASSEMBLY INSTRUCTIONS



## Floor Lamp

- Carefully remove all lamp parts from the box.  
Please see list of items included in box.
- Lay lamp base (A1) on a flat surface.
- Attach lamp base (A2) onto lamp base (A1) by screwing the rod located inside of lamp base (A1) to nut located on end of lamp base (A2).
- Secure lamp bases (A1 and A2) by sliding in washer (B) and securing with nut (C) onto rod located inside base (A1) and screwing firmly using key (D) - (INCLUDED).
- Stand the now assembled base (A) on a flat surface.
- Insert shade (C) to threading on lamp socket (B).
- Secure shade (C) using lock ring (D).
- Insert bulb (E) - (NOT INCLUDED) onto lamp socket (B).



## IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.


## INSTRUCCIONES DE ENSAMBLE

### Lampara de Piso

- Cuidadosamente remueva de la caja todas las partes de la lampara.  
Por favor consulte la lista de los articulos incluidos.
- Pare la base de la lampara (A) en una superficie plana.
- Inserte el anillo de la pantalla (C) a la rosca del enchufe (B).
- Asegure la pantalla (C) usando rosca (D).
- Inserte la bombilla (E) - (NO INCLUIDO) al enchufe (B).
- Inserte el anillo de la pantalla (C) a la rosca del enchufe (B).
- Asegure la pantalla (C) usando rosca (D).
- Inserte la bombilla (E) - (NO INCLUIDO) al enchufe (B).

## IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Esta lampara tiene un enchufe polarizado (una navaja es mas ancha que la otra) como forma de seguridad para reducir el riesgo de un shock electrico. Este enchufe polarizado entrara en una conexi3n solo de un lado. Si el enchufe no entra en la conexi3n trate al reverso. Si aun asi no entra, contacte a un electricista calificado. Nunca use una extension a menos que el enchufe pueda ser conectado completamente. No altere el enchufe.



ITEMS INCLUDED / ARTICULOS INCLUIDOS				
A+E  LAMP BASE BASE DE LAMPARA	B  WASHER ROSCA C  NUT TUERCA	D  KEY LLAVE	F  HARP ARPA	G  LOCK RING ROSCA