


ASSEMBLY INSTRUCTIONS

Nova 1960 Accent Floor Lamp

1. Carefully remove all lamp parts from the box.
2. Stand lamp base (A) on level surface.
3. Insert bulb (B) into socket (C).
4. Attach glass shade (D) by inserting spring clips (F) into slot (E) on glass shade, rotate glass shade until slot is facing down and both clips are secured inside. The clips will keep shade in place.
5. Repeat steps 3 and 4 to the other remaining bulbs (B) and glass shades (D).




IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

INSTRUCCIONES DE ENSAMBLE

Nova 1960 Accent Lampara de piso

1. Cuidadosamente remueva de la caja todas las partes de la lampara.
2. Poner en el piso base (A) en superficie plana.
3. Poner foco (B) en el soquet (C).
4. Poner pantalla de vidrio (D) metiendo los seguros (F) por la ranura (E), de vuelta a la pantalla de vidrio asta que la ranura quede acia abajo y la pantalla fija con los seguros. Los seguros mantienen la pantalla fija.
5. Repita pasos 3 y 4 para los focos (B) restantes y pantallas de vidrio (D).



REPLACE THE BULB

1. Rotate glass shade (a) until clips (c) are out of the slot (b)
2. Replace bulb (d).
3. Replace glass shade (a) by inserting spring clips (c) into slot (b) on glass shade, rotate glass shade until slot is facing down and both clips are secured inside.

REEMPLAZA EL FOCO

1. De vuelta al a pantalla de vidrio (a) asta que los seguros (c) salga por la ranura (b).
2. Remplace foco (D).
3. Poner pantalla (a) meteindo los seguros (c) por la ranura (b) de la pantalla de vidrio, de vuelta a la pantalla asta que la ranura quede acia abajo y la pantalla fija con los seguros.

IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Esta lampara tiene un enchufe polarizado (una navaja es mas ancha que la otra) como forma de seguridad para reducir el riesgo de un shock electrico. Este enchufe polarizado entrara en una conecion solo de un lado. Si el enchufe no entra el la conecion trate el reverso. Si aun asi no entra, contacte un electricista calificado. Nunca use una extension a menos que el enchufe pueda ser conectado completamente. No altere el enchufe.