


ASSEMBLY INSTRUCTIONS

Criss Cross Floor Lamp

1. Carefully remove all lamp parts from the box.
2. Stand lamp base (A1) on a flat surface.
3. Attach lamp base (A2) to lamp base (A1) by screwing in firmly.
4. Insert harp (B) to metal bracket (C).
5. Secure harp (B) by sliding metal part (D) over bracket (C).
6. Attach shade (E) to harp (B) and secure with finial (F).
7. Insert bulb (G) - NOT INCLUDED.



IMPORTANT SAFETY INSTRUCTIONS

This lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

INSTRUCCIONES DE ENSAMBLE

Criss cross Lampara de Piso

1. Cuidadosamente remueva de la caja todas las partes de la lampara.
2. Pare la base de la lampara (A1) en una superficie plana.
3. Asegure base (A2) a base (A1) atornillandolo.
4. Inserte el arpa (B) en el soporte (C).
5. Asegure el arpa (B) deslizando la parte metalica (D) sobre el soporte (C).
6. Ponga la pantalla (E) en cima de el arpa (B) y asegure con la parte (F).
7. Inserte bombilla (G) - NO INCLUIDO.

IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Esta lampara tiene un enchufe polarizado (una navaja es mas ancha que la otra) como forma de seguridad para reducir el riesgo de un shock electrico. Este enchufe polarizado entrara en una conecion solo de un lado. Si el enchufe no entra en la conecion trate el reverso. Si aun asi no entra, contacte un electricista calificado. Nunca use una extension a menos que el enchufe pueda ser conectado completamente. No altere el enchufe.

